

East Rink Scoreboard Instructions

New Game:

- 1. Press MENU, ENTER
- 2. Press EDIT, SET MAIN CLOCK, enter desired time, ENTER
- 3. Press COUNT UP/DOWN, press "2"
- 4. Press AUTO HORN, Press "1"
- 5. Use START and STOP buttons to run clock

Entering a Penalty:

- 1. Press PLAYER PENALTY (Home or Guest)
- 2. Enter player number
- 3. Enter penalty time, press ENTER

To Remove Penalties:

1. Press DELETE PENALTY (Home or Guest), press ENTER

Next Period:

- 1. Press PERIOD +1
- 2. Press EDIT, SET MAIN CLOCK, enter desired time, ENTER If you need to reset only the period # showing:
 - 1. Press EDIT, PERIOD +1, CLEAR/NO
 - 2. Type in the desired period (I.E 2) and press ENTER/YES

Changing Clock/Game Time:

1. Press EDIT, SET MAIN CLOCK, enter desired time, ENTER

Set/ Reset Score:

- 1. To increase score, Press SCORE +1 on either Home or Guest panel
- 2. To decrease score, Press SCORE -1 on either Home or Guest Panel